CONCORD ULTIMAX



# Using the ULTIMAX child car seat

0236-02

To safeguard your child you have opted for our CONCORD ULTIMAX seat. This product is manufactured under strict quality controls. Its excellent safety features work best when the seat is used in accordance with legal requirements. Be sure, therefore, to comply fully with the instructions for its installation and use.
The ULTIMAX is suitable for infants from birth up to 18 kg or for children up to the age of approx. 4 years. The seat may be used on all seats in your car fitted with a three-point seat belt. On the basis of accident statistics, we recommend using the seat behind the passenger seat.
The child car seat comprises three parts: seat shell (A), base unit (B) and
reboard wedge (C).
The seat can also be engaged in four different seat positions when facing forwards and in one position when rear-facing.
The seat shell must not be removed while the child is still seated in it.

**Summary of contents:**


1. Rear-facing installation (from birth to 13 kg).
2. Front-facing installation (from 9 to 18 kg).
3. Securing the child.
4. Adjusting the head support / adjusting the seat to the child's size.
5. Releasing and removing the seat.
6. Removing the cover / removing the pelvic insert.
7. Care instructions
8. Important information
9. Warranty terms
10. General information


0106-02



## 1. Rear-facing installation (from birth to 13 kg)

0237-02

### 1.1

0014-07




**Important!**
**Do not use on seats with airbags.**
**Extreme danger!**

Turn the rotary handle at the front of the seat shell upwards (1) and at the same time push the seat shell into the upright position (2).

### 1.2

0017-06

Hold the seat shell with your thumbs on the left and right side and use your fingers to pull the grey levers as far as they will go in the direction of the arrow. Keep the levers extended and lift the seat shell upwards and out until the **green** component is visible above the snap mechanism. Then release the levers and remove the seat shell.

### 1.3

0013-04

Insert the base unit into the car seat as illustrated.
Position the reboard wedge (**green**) as shown.

# 1. Rear-facing installation (from birth to 13 kg)

0238-01

## 1.4

0101-03




Pass the car seat belt over the top of the base unit and secure the belt in the buckle.

## 1.5

0028-05

Position the lower belt section (1) (lap belt) under the **blue** lap belt guides (see illustration). Pass the upper belt section (2) (diagonal belt) around the outside of the base unit and insert it into the **blue** belt clip. Tension the belt as shown in the illustration, and close the **blue** belt clip.



# 1. Rear-facing installation (from birth to 13 kg)

0239-01

## 1.6




Wrong belt positioning!



## 1.7

0118-04

Belt positioning when the base unit is installed correctly.



# 1. Rear-facing installation (from birth to 13 kg)

0240-02

**1.8**

0088-08




Hold the seat shell as illustrated and position it on the base unit. Press the seat shell downwards until it clicks audibly into position.

**1.9**

0090-06





Always check that when the seat shell is inserted a **green** dot is visible **on both sides** through the opening on the sidepieces. This indicates that the seat is installed correctly.

**When rear-facing the seat may only be used in the upright position! If the child's body weight exceeds 8 kg, the factory-fitted pelvic insert should be removed, see section 6.5.**
**Disassembly is done in the reverse order.**

## 2. Front-facing installation (from 9 to 18 kg)

0241-01

**2.1**

0014-07




**Important!**
**Front-facing installation is only suitable from a body weight of 9 kg and without the pelvic insert, see section 6.5!**

Turn the rotary handle at the front of the seat shell upwards (1) and push the seat shell into the upright position (2).

**2.2**

0017-06

Hold the seat shell with your thumbs on the left and right side and use your fingers to pull the grey levers as far as they will go in the direction of the arrow. Keep the levers extended and lift the seat shell upwards and out until the **green** component is visible above the snap mechanism. Then release the levers and remove the seat shell.

**2.3**

0010-04

Insert the base unit into the car seat as illustrated. Position the reboard wedge **(green)** as shown.

## 2. Front-facing installation (from 9 to 18 kg)

0242-01

**2.4** 0030-04




Pass the car seat belt over the top of the base unit and secure the belt in the buckle.

**2.5** 0031-05



Insert the lower belt section (lap belt) into the lap belt guides (**red**) as illustrated.

**2.6** 0032-05



Open the **red** belt clip on the belt tensioner.

## 2. Front-facing installation (from 9 to 18 kg)

0243-02

**2.7** 0029-08



Turn the open side of the ratchet shaft upwards.

**2.8** 0037-09



Position the upper belt (diagonal belt) in the opening of the ratchet shaft and into the guide mechanism behind it.

**The belts must not be twisted!**

## 2. Front-facing installation (from 9 to 18 kg)

0244-01

**2.9** 0039-07




Tighten the upper belt (1) slightly and close the **red** belt clip (2). Then tighten the belt once again.

**2.10** 0041-07



Use the ratchet to wind the belt up until the base unit is firmly secured in the car seat.

**The belt must be taut.**

**The base unit must be positioned straight on the car seat, parallel to the direction of travel. Move the base unit to adjust if necessary and then tighten the belt again.**

**2.11** 0069-08



The car safety belt must be threaded through **all three** belt guides.

## 2. Front-facing installation (from 9 to 18 kg)

0245-01

### 2.12

0073-05



The buckle for the vehicle safety belt must not come above the edge of the lap belt guide.

If in doubt or if you are still uncertain, please contact CONCORD.

### 2.13

0121-03

Belt positioning when the base unit is installed correctly.



## 2. Front-facing installation (from 9 to 18 kg)

0246-00

**2.14**

0048-09




Hold the seat shell as illustrated and position it on the base unit. Press the seat shell downwards until it clicks audibly into position.

**2.15**

0050-07



Always check that when the seat shell is inserted a **green** dot is visible **on both sides** through the opening on the side pieces. This indicates that the seat is installed correctly.

Disassembly is done in the reverse order (see 1.1 and 1.2).

To release the belt tensioner see Chapter 5.

## 3. Securing the child

0247-00

### 3.1

0036-06



The central adjuster is located at the front of the seat, beneath the cover. This secures the central belt.

Release the central adjuster by pushing the small flap up (see illustration), and then pull the belt forwards (do not pull on the **belt padding**!).

### 3.2

0056-06



Open the belt buckle and open the child seat belts outwards to lie on the armrests. Then put the child into the seat shell so that its back rests against the backrest.

## 3. Securing the child

0248-02

### 3.3

0058-06




Fit both belt parts together (see illustration) and push them into the belt buckle so that they engage with an audible “click”.

### 3.4

0059-05

Tension the belt system by pulling the belt of the central adjuster until your child is securely strapped in. Please check that both the shoulder and lap belts are tensioned equally. To take the child out, press the red “Press” button on the belt buckle of the harness system.

## 4. Adjusting the seat to the child's size / adjusting the head support and harness

0249-03

### 4.1

0033-05

Grasp the head support at the top and pull it forwards. You can then set it to the height that is right for your child. There are six possible different positions.

**Attention! Always make sure the belt is positioned correctly, as shown in 4.2, illustration (A).**

### 4.2

0105-04




When the child is strapped in, the shoulder belt should feed horizontally to the back or incline slightly upwards, see illustration (A). If the shoulder belt feeds downwards as shown in the illustration (B), then the belt must be repositioned and inserted through the next slot up.
To do this proceed as follows:

### 4.3

0034-02



**To adjust the shoulder belt positions, the seat shell must be removed from the base unit (see 1.1 and 1.2)!**

Pull away the back trim located on the back of the seat shell.

## 4. Adjusting the seat to the child's size / adjusting the head support and harness

0250-02

### 4.4

0036-06



The central adjuster is located at the front of the seat, beneath the cover. This secures the central belt.

Release the central adjuster by pushing the small flap up (see illustration), and then pull the **belts** through to the front (do not pull on the **belt padding**!).

### 4.5

0040-04





On the rear of the seat shell, separate the two belts from the connecting piece.

## 4. Adjusting the seat to the child’s size / adjusting the head support and harness

0251-01

### 4.6

0123-04



Pull the two metal clasps on the back of the seat out of their recesses and fit them through the belt openings in the seat shell.

### 4.7

0042-07



Then pull the two belts out to the front through the backrest and the seat cover.
Now thread both belts from the front through the cover and into the required slot.

On the back you must thread both belts back into the connecting piece, then tighten the belt at the front by the central belt.

**Please check that the left and right harness belts are both adjusted in the same way.**

## 4. Adjusting the seat to the child's size / adjusting the harness / shortening the belts

0252-02

**4.8**

0124-03




On the back of the seat, clip the metal clasps back into position. They must engage with an audible "click".

Thread the belts back into the connecting piece, as shown in the illustration.

Finally, clip in the back trim.

**4.9**

0143-04



**When does the belt system need to be shortened?**

If you cannot tighten the child seat belt sufficiently by pulling on the central adjuster at the front of the seat, then it will be necessary to shorten the belt system.

To do this proceed as follows:

## 4. Adjusting the seat to the child’s size / shortening the belts

0253-01

### 4.10

0045-05



Remove the seat shell from the base unit and lay the shell **upside down** on a clean surface. Release the elastic tapes on the cover and pull the cover back a little. Lever out the metal clasps secured on the bottom of the shell, and thread them through the large side opening and the small slot (see illustration).

### 4.11

0051-06



Now press the metal clasps from the outside into the recess.

**Both sides must be adjusted equally!**

## 4. Adjusting the head support / adjusting the seat to the child's size

0254-01

**4.12**

**When does the shortened belt system need to be returned to its lengthened setting?**

If, after releasing the child seat belt by means of the central adjuster, it does not pull forwards sufficiently to allow the belt system to be closed, then the belt system needs to be lengthened.

To do this proceed as follows:

**4.13**




Remove the seat shell from the base unit and lay the shell **upside down** on a clean surface.

Release the elastic tapes on the cover and pull the cover back a little. Lever out the metal clasps secured on the side of the shell and push them back through their slots.

**4.14**




Now press the metal clasps from the outside into the recess. The clip must engage with an audible "click".

**Both sides must be adjusted equally!**

## 5. Releasing the belt tensioner to remove the seat

0255-01

### 5.1

0046-06



First open the **red** belt clip.

### 5.2

0043-08




Releasing the belt tensioner on the base unit when installed facing the front:

Pull the **grey** lever on the belt tensioner upwards with the thumb of your left hand until you can push the small **grey** button upwards (1) until there is no tension on the belt. Keep the **grey** button in this position (2), and at the same time press the lever down (3).

## 6. Removing the cover / removing the pelvic insert

### 5.3

0086-06



Keep pressing the **grey** lever on the belt tensioner down and pull the car seat belt in the direction of the arrow to unwind it from the ratchet shaft.

Continue removing the seat in the reverse order to its installation.

### 6.1

0071-06

**To remove the cover, the seat shell must be removed from the base unit.**

Undo the seat belt buckle. Release the elastic tapes located on the back of the cover at the points marked in red in the illustration.



## 6. Removing the cover / removing the pelvic insert

0257-01

### 6.2

0096-06



Lay the seat shell upside down on a clean surface. Lever out the metal clasps secured on the side or bottom of the shell and push them back through their slots as illustrated.

### 6.3

0095-03



Pull the buckle padding away from the belt buckle and thread the belt buckle down and out through the cover.

## 6. Removing the cover / removing the pelvic insert

0258-00

**6.4** 0074-04



Remove the cover carefully from the seat shell.

To fit the cover, proceed in the reverse order.

**6.5** 0117-02



If the child's body weight exceeds 8 kg, the factory-fitted pelvic insert should be removed. This is located on the surface of the seat beneath the seat cover.

## 7. Care instructions

Removing the seat covers to wash:

The cover is composed of two parts which are secured to the seat by means of Velcro tape, buttonholes and tapes. Once these ties have been released the two parts of the cover may easily be removed. To fit the covers, proceed in the reverse order (seat shell and head section).

When they come into contact with moisture, especially during washing, the cover fabrics can easily fade. Do not use solvents!

## 8. Important information



**Please note the instructions in the car's operating manual for transporting children in a car. Information on the use of child seats together with an airbag should be observed with particular care.**

Children sometimes have items in their jacket or trouser pockets (e.g. toy) or wear hard items that are attached to their clothes (e.g. belt buckle). Check that these items do not come between the child and the safety belt – they could cause unnecessary injuries in the event of an accident. These hazards also apply to adults!

Naturally children can often be very lively. You should therefore explain to children how important it is to always be safely fastened in. Children must understand that they should never change the way the belts are positioned, and never open the buckle.

Only if safety equipment is correctly installed and used can your child enjoy maximum safety.

All straps in the child restraint system and all belts required for securing the seat in the car must be fitted tautly and without twists, and must be protected against damage.

Protect those parts of the restraint system that are not covered in fabric from direct sunlight to avoid your child being burned.

The child restraint system must not be damaged or trapped by moving parts in the car interior or by doors.

Never modify the restraint system in any way – this will endanger your child's safety.

After an accident the whole child restraint system must be replaced or returned to the manufacturer for testing along with a report of the accident.

## 8. Important information

0260-01

You should also tell your passenger how to remove the child in the event of an accident or danger.

The belts may only be routed via the points of contact for the belt on the seat and the positions stated in the user instructions. Belts must not be routed in any other way.

The lap belts on the harness system must be fitted as low down as possible so that the child's hips are held correctly.

The child seat may not be used in conjunction with active front airbags (risk of death)!

Do not leave your child in the child car seat unsupervised whether strapped in or not.

Secure luggage and other items to reduce the risk of injury in the event of an accident.

The user instructions must always accompany the child car seat.

The use of accessories and replacement parts is not permissible and shall lead in the event of contravention to the expiry of all claims under the warranty and of all liability claims. Only special CONCORD original accessories are excluded.

The child car seat must always be used with its original covers.

Suitable for cars with three-point (lap and diagonal) seat belts tested in accordance with ECE Regulation 16 or a comparable standard.

As the period of use for this restraint system (ULTIMAX) is very long, it is natural that seat covers and other used parts will each receive different degrees of wear and tear depending on the individual duration and intensity of use and will need to be replaced. For this reason it is not possible to give a blanket warranty of durability extending beyond a six-month warranty period.

For additional purchases, please contact your local specialist child and baby shop, specialist departments in department stores, car accessories centre or mail order companies. There you will also be able to buy the full range of accessories for CONCORD child's car seats.

The ULTIMAX child car seat has been tested in a simulated head-on crash at an impact speed of 50 kph against a solid obstacle. This complies with the international test standard ECE R 44 04 which forms the basis for all tested restraint systems. If used according to legal requirements, and given adherence to the instructions for installation and use, this device should prevent or reduce injury to children up to three years of age or with a body weight of up to 18 kg in the event of an accident, depending on the type and severity of accident.

As is the case with the use of safety belts for adults, a child safety device does not replace the need for responsible and prudent driving behaviour.

## 9. Warranty terms

0261-01

The warranty shall commence from the time at which the seat is purchased. The warranty period shall correspond to the legal warranty period for the sale of child seats applicable in the end user's country. The contents of the warranty shall comprise the remedy of a defect, the supply of a replacement, or a price reduction, at the manufacturer's discretion.

The warranty shall pertain only to the first user.

In the event of a defect, rights under the warranty shall only be considered if the specialist dealer is notified of the defect immediately after its first occurrence.

If the specialist dealer is unable to resolve the problem, then the dealer shall return the product to the manufacturer along with a precise description of the complaint and an official receipt showing the date of purchase.

The manufacturer accepts no responsibility for products he has not supplied.

The right to make a claim under the warranty shall not apply if:

- the product has been altered;
- the product has not been returned to the dealer together with the receipt within 14 days after the occurrence of the defect;
- the defect has arisen as a result of incorrect handling or maintenance, or as the result of any other fault on the part of the user, in particular if the instructions for use have not been observed;
- repairs have been made to the product by a third party;
- the defect has been caused by an accident;
- the serial number has been damaged or removed.

Alterations to or deterioration in the product brought about by use in accordance with the contract (wear and tear) do not constitute a warranty claim.

The warranty period shall not be extended as a result of services rendered by the manufacturer in the event of a warranty claim.

## 10. General information

1. This is a "universal" child restraint system. It is approved for general use in vehicles in accordance with UN-ECE Regulation 44, Amendment 04 and fits most, but not all, passenger vehicle seats.
2. It can be assumed that the system will fit correctly if the vehicle manufacturer states in the vehicle manual that the vehicle is suitable for the installation of a "universal" child restraint system for the relevant age group.
3. This child restraint system has been classified as being of the "universal" class, satisfying stricter conditions than previous models which do not bear this label.
4. If in doubt, please consult the manufacturer of the child restraint system or the retailer.
5. Only suitable for vehicles with three-point (lap and diagonal) seat belts tested and approved in accordance with UN-ECE Regulation 16 or a comparable standard.

0145-06

Um die Funktionsfähigkeit und Sicherheit Ihres Kinderautositzes auch nach einem Austausch von Ersatz- und Zubehörteilen zu gewährleisten, bitten wir Sie bei Bestellungen Ihrem Fachhändler nachstehende Angaben mitzuteilen:

To ensure the maximum efficiency of your child car safety seat after the exchange of the covers or spare parts ask your retailer about following information:

Pour assurer une efficacité optimale de votre siège auto après l'échange de housses ou de pièces détachées, demandez à votre détaillant l'information suivante:

Per garantire la funzionalità e la sicurezza del vostro seggiolino da auto per bambini anche dopo una sostituzione di parti di ricambio o accessori, vi preghiamo di comunicare al vostro negozio di fiducia specializzato i seguenti dati al momento di emettere l'ordine:

Para seguir garantizando el correcto funcionamiento y la seguridad de su silla infantil para automóvil después de un cambio de piezas o accesorios, le rogamos que indique los siguientes datos al realizar pedidos a su comercio especializado:

Para garantir a funcionalidade e a segurança da sua cadeira de criança para automóvel após a substituição de peças e acessórios, agradecemos que comunique os seguintes dados ao seu distribuidor:

Om de functionaliteit en de veiligheid van het door u gekochte autokinderzitje ook na vervanging van onderdelen en accessoires te waarborgen, is het belanggrijk dat u bij de bestelling in uw speciaalzaak onderstaande gegevens vermeldt:

**CONCORD**
Industriestrasse 25
95346 Stadtsteinach

universal
- 18 kg

$E_1$

1 04.....
2 0000000

☐ **CONCORD ULTIMAX**

.....

1 ECE-Nr. / ECE-no. / N° de série / N° ECE / Número ECE

.....

2 Serien-Nr. / serial-no. / N° di serie / Número de serie

.....

Ersatzteil / Seat type / Type de siège / Parte di ricambio / Pieza de repuesto /Peça / Type kinderzitje

.....

Fachhändler / Dealer / Commerçant spécialisé / Negozio specializzato / Comercio especializado / Distribuidor / Speciaalzaak

.....

.....

.....

Meine Anschrift / my address / Mon adresse / Il proprio indirizzo / Mi dirección / Meu endereço / Mijn adres